

# Riverside Community College

## Physics 4-C

---

### LABORATORY REPORT 6

Do Lenses do the thing?

---

**Author: Marlon Lopez**

Lab Partner: Chris Stark

**Professor**

Dr. Russel

Date of experiment : 04/15/2024

# 1 Introduction

This lab's goal will be to test the Thin lens law which will result with a focal point for the corresponding lens, as well as making sure the magnification equation for a thin lens holds true.

## 2 Methodology

We will use three different lenses to test the Thin lens law as well as checking if the Magnification equation is indeed true. The process should be the same for your three different lenses

### 2.1 Setup

1. We utilized a PASCO metallic rail 1.6 meters in length where the measurements are marked on the rail. A light source from PASCO and a plastic board from PASCO .
2. Measure the height of the Image on the PASCO light source,  $h_o$ . We measured from the two tips of the arrows, I'll refer to this as my points of reference.
3. Position a lens on the track so that it starts at 20 cm. <sup>1</sup>

### 2.2 Procedure

What lens you use should not change the procedure as it is identical for all three lenses you will use in this lab. The lenses are labeled; Red, Green, Blue.

1. Start the experiment by placing the plastic board on the track.
2. Move the board on the track until you find a position that will allow the object image focus on the board.
3. Log the displacement of the lens, call that  $d_o$ . As well as the distance of the image,  $d_i$ .<sup>2</sup>
4. Measure and log the points of reference on the projected image.
5. Repeat 9 more times, incrementing the light by 5 cm.

---

<sup>1</sup>We found that anything less won't have enough space on the track to focus the image.

<sup>2</sup>An easy way to get this is by measuring the distance to the board,  $x_i$ ) and subtracting that from  $d_o$ ).

### 3 Data

Tabulating our displacement of the lens as well as the white board

| do (cm) | xi (cm) | 1/do (1/cm) | hi (cm) | di (cm) | 1/di 1/(cm) | hi/ho  | negative di/do |
|---------|---------|-------------|---------|---------|-------------|--------|----------------|
| 20      | 112     | 0.05        | 9       | 92      | 0.01087     | -4.5   | -4.6           |
| 25      | 72      | 0.04        | 3.75    | 47      | 0.021277    | -1.875 | -1.88          |
| 30      | 66.1    | 0.033333    | 2.4     | 36.1    | 0.027701    | -1.2   | -1.20333       |
| 35      | 66      | 0.028571    | 1.7     | 31      | 0.032258    | -0.85  | -0.88571       |
| 40      | 68      | 0.025       | 1.4     | 28      | 0.035714    | -0.7   | -0.7           |
| 45      | 71      | 0.022222    | 1.1     | 26      | 0.038462    | -0.55  | -0.57778       |
| 50      | 74.5    | 0.02        | 1       | 24.5    | 0.040816    | -0.5   | -0.49          |
| 55      | 78.3    | 0.018182    | 0.9     | 23.3    | 0.042918    | -0.45  | -0.42364       |
| 60      | 82.7    | 0.016667    | 0.7     | 22.7    | 0.044053    | -0.35  | -0.37833       |
| 65      | 87      | 0.015385    | 0.65    | 22      | 0.045455    | -0.325 | -0.33846       |

Figure 1: Green lens

| BLUE do (cm) | xi (cm) | 1/do (1/cm) | hi (cm) | di (cm) | 1/di 1/(cm) | hi/ho  | negative di/do |
|--------------|---------|-------------|---------|---------|-------------|--------|----------------|
| 30           | 95      | 0.033333    | 4.25    | 65      | 0.015385    | -2.125 | -2.16667       |
| 35           | 86      | 0.028571    | 2.85    | 51      | 0.019608    | -1.425 | -1.45714       |
| 40           | 82.4    | 0.025       | 2.1     | 42.4    | 0.023585    | -1.05  | -1.06          |
| 45           | 83      | 0.022222    | 1.7     | 38      | 0.026316    | -0.85  | -0.84444       |
| 50           | 85      | 0.02        | 1.4     | 35      | 0.028571    | -0.7   | -0.7           |
| 55           | 88.1    | 0.018182    | 1.2     | 33.1    | 0.030211    | -0.6   | -0.60182       |
| 60           | 91.6    | 0.016667    | 1.1     | 31.6    | 0.031646    | -0.55  | -0.52667       |
| 65           | 95.3    | 0.015385    | 0.95    | 30.3    | 0.033003    | -0.475 | -0.46615       |
| 70           | 99.3    | 0.014286    | 0.8     | 29.3    | 0.03413     | -0.4   | -0.41857       |
| 75           | 103.7   | 0.013333    | 0.75    | 28.7    | 0.034843    | -0.375 | -0.38267       |

Figure 2: Blue lens

| RED do (cm) | xi (cm) | 1/do (1/cm) | hi (cm) | di (cm) | 1/di 1/(cm) | hi/ho   | negative di/do |
|-------------|---------|-------------|---------|---------|-------------|---------|----------------|
| 20          | 40      | 0.05        | 1.975   | 20      | 0.05        | -0.9875 | -1             |
| 25          | 42.1    | 0.04        | 1.35    | 17.1    | 0.05848     | -0.675  | -0.684         |
| 30          | 45.1    | 0.033333    | 1       | 15.1    | 0.066225    | -0.5    | -0.50333       |
| 35          | 49      | 0.028571    | 0.775   | 14      | 0.071429    | -0.3875 | -0.4           |
| 40          | 53.3    | 0.025       | 0.65    | 13.3    | 0.075188    | -0.325  | -0.3325        |
| 45          | 57.8    | 0.022222    | 0.55    | 12.8    | 0.078125    | -0.275  | -0.28444       |
| 50          | 62.7    | 0.02        | 0.5     | 12.7    | 0.07874     | -0.25   | -0.254         |
| 55          | 67.1    | 0.018182    | 0.45    | 12.1    | 0.082645    | -0.225  | -0.22          |
| 60          | 72.1    | 0.016667    | 0.4     | 12.1    | 0.082645    | -0.2    | -0.20167       |
| 65          | 77      | 0.015385    | 0.35    | 12      | 0.083333    | -0.175  | -0.18462       |

Figure 3: Red lens

## 4 Analysis

### 4.1 Calculations

1. We will be verifying the Thin lens law by determining a linear relationship.  

$$\frac{1}{d_o} + \frac{1}{d_i} = \frac{1}{f}$$
2. You start off by subtracting  $\frac{1}{d_o}$  to both sides of the equation.  $\frac{1}{d_i} = -1(\frac{1}{d_o}) + \frac{1}{f}$
3. We notice that  $\frac{1}{d_i}$  corresponds to the y axis,  $\frac{1}{d_o}$  corresponding to the x axis, and  $\frac{1}{f}$  to the y intercept.

### 4.2 Interpretation

Plotting out our  $\frac{1}{d_i}$  vs  $\frac{1}{d_o}$ , we should get a slope from our equation  $\frac{1}{d_i} = -1(\frac{1}{d_o}) + \frac{1}{f}$ . Where we said x is  $\frac{1}{d_o}$  meaning that for our data to show that the thin lens law is true, our slope should be -1.

From this we can find the focus point for each lens by taking the reciprocal of the y intercept.

From our table.1, we can check the magnification law  $\frac{h_i}{h_o} = -\frac{d_i}{d_o}$  by seeing if the corresponding columns are equal.

Finding the slope for the Green, Blue, and Red lenses:




Figure 4: Green Lens




Figure 5: Blue Lens




Figure 6: Red Lens

## 5 Result

The Green lens was found to have a focus of 16.4745 cm, Blue had a focus of 20.7469 cm, and Red having focus of 10.0402 cm. Our experimental values for  $\frac{h_i}{h_o}$  and  $-\frac{d_i}{d_o}$  showed that those values were approximately equal which indicates that the magnification equation is indeed true.

## 6 Conclusion

With this experiment we experimentally determined that the Thin lens law was indeed correct as well as seeing if the magnification of an image equation to be true.<sup>3</sup>

One thing to note with our data is that there might be slight discrepancy's as the projected image got smaller it was more difficult to accurately get a measurement.

## 7 References

- [1] Dr. Russel's Lecture 4/15/24, Riverside Community College.

Special thanks to my Grandma for making me breakfast before this lab!

---

<sup>3</sup>For thin lenses